42"Tinsel 3D Snoopy In Santa Suit(No Bead)

SKU#423-122

Parts List:

A	B	C
D	E	

Pr*ductW*rks

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

A) Do not use extension products (adapter) unless marked suitable for indoor and outdoor use. Do not use outdoors unless this product is marked suitable for outdoor use. Use Ground Fault Circuit Interrupter (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.

B) Use only with the transformer provided. Use intended for permanent installation or use.

C) Do not expose or allow water pack or electric adapters, fireplaces, candles, or other similar sources of heat.

D) Do not attempt service this setting of the product with displays or wells, or pieces or similar items or wells.

E) Do not let children watch or the display unit is on any area.

F) Unplug the product when leaving the house, when retiring for the night, or if left unattended.

G) This is an electric product not a toy! To prevent risk of fire, burns, personal injury and damage to the product, children should not be allowed to play with this product. Never leave the product on when it is unattended.

H) Do not use the product for more than its intended use.

I) Do not hang ornaments or other objects from cord, wire, or light string.

J) Do not expose to rain or dampness, as the product or extension cords as this may damage the wiring insulation.

K) Do not cover the product with cloth, paper or any material as part of how product when in use.

L) This product is illustrated with push-in base lamps. Do not twist loose.

M) This product electrical overload protection (fuse). If more than indicates an overload is present, the product will not work. Unplug the product from the outlet and check for any additional damage or products that may be attached to the product. Replace the fuse with the same type and rating. If the product still does not work, discontinue using and check the product. If the replacement fuse blows, a short circuit may be present and the product should be discarded.

N) Do not use the product for other than its intended purpose. Failure to comply with the manual instructions may result in damage to the product and/or injury to the user.

pSAVE THESE INSTRUCTIONS

Hot and Cold Instructions

a. Read the instructions and keep in a safe place, this may should be well maintained and clean. Do not place on the floor or where the cables and screw or inside of walls. Keep the may hidden filled with water.

b. Before using or moving, inspect product carefully. Damaged any products that have not damaged, or frayed wire connection or cords, cracks in the lamp/fixture, or enclosures, or any other damage, discontinue use immediately.

c. When storing the product, carefully remove the product from enclosure in a physical, including may, machines, or games, to avoid any control when in sleep, or the product may be damaged or cause injury to the user.

d. When not in use, store safely in a cool, dry location protected from sunlight.

User Servicing Instructions

Replace the Fuse.

a) Unplug plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.

b) Open fuse cover. Slide fuse from access cover or box of fuse holder. Replace with same fuse.

c) Reinsert fuse carefully.

d) Push in fuse. Replace fuse plug with 13 amp, 125 Volt fuse.

e) Close fuse cover.

f) Close fuse cover. Make Sure the fuse is not cover on box of attachment plug.

g) Note: If the fuse still blows, attachment plug. Hardware or wiring device fuses that should not be removed. Discard product if the attachment plug is damaged.

Replace the lamp.

1. Unplug plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Pull lamp and plastic base straight out of lampholder.
3. Replace lamp with only 2.5 Volt, 0.44Watt, base (E5/Miniature wedge base) or equivalent LED mini lamp provided with product.

If the new lamp base does not fit in lampholder, follow the steps.

a) Unplug plug from outlet.

b) Remove the base of bulb/lamp by straightening lamp base and gently and lamp out.

c) Thread ends of new lamp through hole in old base with one lead in each hole.

d) Push base is fully inserted into base, bend each lead out, like other lamps in the light set so that the base will touch the contacts inside the lamphole.

CAUTION

1. To reduce the risk of overheating, replace burned-out lamps promptly. Use 2.5 volt, 0.44watt bulb/Light only.
2. To reduce the risk of fire and electric shock, do not install on base having opening, broken or cracked coverings of metal or materials which block the metal. Do not install and mount or support strings in a manner that can rub or damage wire insulation.

Model No. 23421186

FOR INDOOR AND OUTDOOR USE

120V 60Hz AC

MADE IN CHINA

NORTHBROOK IL 60062

1-224-406-8810

42"Tinsel 3D Snoopy In Santa Suit(No Bead)

SKU#423-122

Parts List:

A	B	C
D	E	



Pr*ductW*rks

NORTHBROOK IL 60062

1-224-406-8810

Instrucciones de servicio para el usuario

Reemplace el fusible.

a) Retire el enchufe y retírelo del receptáculo u otro dispositivo. No tire del cable para desconectarlo.

b) Abra la cubierta del fusible. Deslice el fusible de acceso al fusible en la caja. Reemplace con el mismo fusible.

c) Retire el fusible cuidadosamente.

d) Empuje el fusible. Reemplace el fusible únicamente con uno de 2.5 lámpara, 125 voltios con aumentos con el producto.

e) Cierre la cubierta del fusible. Asegúrese de que la cubierta del fusible de un cable superior en caso de una cubierta.

f) Cierre la cubierta del fusible. Asegúrese de que la cubierta del fusible de un cable superior en caso de una cubierta.

g) Nota: Si el fusible todavía se quema, el dispositivo de conexión o dispositivo de seguridad. Deseche el producto si el enchufe está dañado. Desseche el producto si el enchufe está dañado.

Reemplace de la bombilla.

Paso 1. Tome el enchufe y retírelo del receptáculo o tomacorriente. No tire del cable para desconectarlo.

paso 2. Retire la bombilla y la base plástica hacia fuera de la bombilla.

paso 3. Reemplace la bombilla únicamente con una de 2.5 Volt, 0.44 Watt, (base bi-pin/bombilla reglamentario) de reemplazo o LED tipo de bombilla provistas con el producto.

Si la nueva base de la bombilla no cabe en el portalámpara, siga los pasos siguientes antes del paso 1:

a. Retire la base de la bombilla quitando suavemente la bombilla de la bombilla y habitación suavemente hacia afuera.

b. Inserte los extremos de la nueva bombilla cada a través de los orificios de la base antigua.

c. Empuje la base completamente en la bombilla, de tal forma, bombilla de la base de la bombilla, de tal forma que la base de la bombilla toque los contactos dentro del portalámpara.

PRECAUCIÓN

1. Para reducir el riesgo de sobrecalentamiento, reemplace las bombillas quemadas inmediatamente. Use únicamente bombillas de 2.5 volt, 0.4 watts.
2. Para reducir el riesgo de incendio y descarga eléctrica, no ha instale para montar en paredes que tengan rejas o ranuras cubiertas de metal o materiales que bloquean el metal. No instale ni monte el cable eléctrico en una manera que pueda dañar el aislamiento del cable eléctrico.

Model No. 23421186

PARA USO BAJO TECHO Y A LA INTEMPER

120V 60Hz AC